

LYNX



Lynx RXI-A

<b>Lynx stationary unit RXI-A</b>	
Article number:	LX-R2-I-0000
Application areas:	Machine applications, sensor networks etc
Frequency:	2,405 - 2,480 GHz
Mod. Type:	DSSS (Direct sequence spread spectrum)
Code comb.:	4 billion
Open collector outputs:	2
Radio type:	Low IF topology
Antenna:	Built-in
Power supply:	5-24V DC
Power consumption:	30 mA
Weight:	61 g (1.43 lb)
Temperature:	- 20° C to +55° C
Dimensions:	54 x 96 x 37 mm (2,18 x 3,88 x 1,5 in)
Protection:	IP 65
Recommended hand/stationary unit:	Lynx TXI-A, TXI-B, TXI-C and RXI-A



Midgårdsvägen 20, S-973 34 LULEÅ  
Tel: 0920-22 24 10, Fax: 0920-22 24 20  
E-Mail: [info@vianetab.se](mailto:info@vianetab.se)  
Gsm: 070-545 14 52, 070-545 17 81

**TELE RADIO AB**

Sweden, Main office  
Tel. +46 (0)31-724 54 60  
e-mail: [info@tele-radio.com](mailto:info@tele-radio.com)

[www.tele-radio.com](http://www.tele-radio.com)

**TELE RADIO SVERIGE**

Sweden  
Tel. +46 (0)31-724 98 00  
e-mail:  [sverige@tele-radio.com](mailto: sverige@tele-radio.com)

**TELE RADIO OÜ**

Estonia  
Tel. +372 44 511 55  
e-mail: [m.jyrissoo@tele-radio.com](mailto:m.jyrissoo@tele-radio.com)

**TELE RADIO GmbH**

Germany  
Tel. +49 (0)94 51-944 8 550  
e-mail: [kontakt@tele-radio-gmbh.de](mailto:kontakt@tele-radio-gmbh.de)

**TELE RADIO ASIA**

China  
Tel. +86-(0)592-3111168  
e-mail: [b.sun@tele-radio.cn](mailto:b.sun@tele-radio.cn)

**TELE RADIO TURKEY**

Turkey  
Tel. +90-532 292 4448  
e-mail: [c.mevlevioglu@tele-radio.com](mailto:c.mevlevioglu@tele-radio.com)

**TELE RADIO LTD**

England  
Tel. +44 (0) 1625 509125  
e-mail: [sales@teleradiouk.com](mailto:sales@teleradiouk.com)

**TELE RADIO LLC**

North America & Latin America  
Tel. +1 (305) 459 0763  
e-mail:  [america@tele-radio.com](mailto: america@tele-radio.com)

**TELE RADIO BV**

Benelux  
Tel. +31-(0)70-419 41 20  
e-mail: [info@teleradio.nl](mailto:info@teleradio.nl)

**TELE RADIO AS**

Norway  
Tel. +47-6933 4900  
e-mail: [norway@tele-radio.com](mailto:norway@tele-radio.com)